




VIDEO TUTORIAL

Important!

This replacement procedure can be used for:
VW TOURAN (1T3) 1.6 TDI

The steps may slightly vary depending on the car design.

REPLACEMENT: COIL SPRINGS – VW TOURAN 1T3. TOOLS YOU NEED:



- Wire brush
- WD-40 spray
- 12-point socket 15/16"
- Combination spanner #18
- Combination spanner #21
- XZN socket bit # 6
- XZN socket bit # 14
- Drive socket # 13
- Drive socket # 14
- Drive socket # 16
- Drive socket # 18
- Drive socket # 21
- HEX bit No.H6.
- Torque wrench
- Ratchet wrench
- Tap wrench
- Copper grease
- Hydraulic strut spring compressor
- Wheel impact socket #17
- Flat chisel
- Hammer
- Hydraulic transmission jack
- Rubber mallet
- Crow bar
- Wheel chock

Replacement: coil springs – VW Touran 1T3. Professionals recommend:

- Both coil springs of the front suspension should be replaced simultaneously.
- The replacement procedure is identical for the left and right coil springs of the front suspension.
- Please note: all work on the car – VW Touran 1T3 – should be done with the engine switched off.

CARRY OUT REPLACEMENT IN THE FOLLOWING ORDER:

1



Secure the wheels with chocks.

2



Open the bonnet.

3



Remove the windscreen wiper arm nut covers.

4



Unscrew the fasteners of the windscreen wiper arms. Use a drive socket #14.

5



Remove the wiper arms.

6



Remove the cowl grille seal.

7



Raise up and remove the cowl grille.

8


Clean the fasteners of the shock absorber upper mount. Use a wire brush. Use WD-40 spray.

9


Unscrew the upper fastening of the shock absorber strut. Use a drive socket #13.

AUTODOC recommends:

- VW Touran 1T3 – To avoid injury, hold the suspension strut while unscrewing the fastening bolts.

10



Loosen the wheel mounting bolts. Use wheel impact socket #17.

11



Unscrew the wheel bolts.

AUTODOC recommends:

- Warning! To avoid injury, hold the wheel while unscrewing the fastening bolts. VW Touran 1T3

12



Remove the wheel.

13



Remove the wheel rim cover.

14



Install the wheel.

AUTODOC recommends:

- Warning! To avoid injury, hold the wheel while screwing in the fastening bolts on the car. VW Touran 1T3

15



Screw in the wheel bolts. Use wheel impact socket #17.

16



Loosen the wheel hub bolt. Use 15/16" drive 12-point socket.

Replacement: coil springs – VW Touran 1T3. AUTODOC experts recommend:

- Do not unscrew the fastener by more than 90 degrees.

17



Raise the front of the car and secure on supports.

18



Unscrew the wheel bolts.

19



Remove the wheel.

AUTODOC recommends:

- Warning! To avoid injury, hold the wheel while unscrewing the fastening bolts. VW Touran 1T3

20



Disconnect the wiring and the brake hose from the bracket on the shock strut.

21



Clean the fasteners connecting the stabiliser link to the shock strut, and those connecting the shock strut to the steering knuckle. Use a wire brush. Use WD-40 spray.

22



Unscrew the nut and remove the stabilizer rod from the shock strut. Use a combination spanner #18. Use XZN #6.


23

Remove the level control system sensor from the suspension control arm.

Please note!

- Some cars are not equipped with level control system sensors.

24



Unscrew the nut and remove the shock absorber lower mounting bolt. Use a combination spanner #18. Use XZN #14.

25



Prop up the steering knuckle. Use a hydraulic transmission jack.

26




Disconnect the steering knuckle from the shock absorber strut. Use a flat metal-working chisel. Use a hammer.

27



Unscrew the fastener connecting the drive shaft to the wheel hub. Use 15/16" drive 12-point socket. Use a tap wrench.

28




Unscrew the fastener connecting the ball joint to the suspension control arm. Use a drive socket #16.

29



Disconnect the spherical joint from the arm. Use a crowbar.

30




Remove the drive shaft from the wheel hub.

31



Remove the suspension strut.

32



Set the shock absorber strut on the spring compressor tool.

Replacement: coil springs – VW Touran 1T3. AUTODOC recommends:

- Note that when using a spring compressor, spring coils need to be securely gripped, compressing the spring on the opposite sides.
- Ensure the correct position of the spring in the retainer.
- Make sure that the spring coils tightly entered the lock handles.

33



Compress the spring.

34




Unscrew the top fastening of the shock strut mount. Use a combination spanner #18. Use HEX No.H6.

35



Remove the top strut mount.

36



Release the coil spring.

37



Remove the spring.

38



Clean the coil spring mounting seats. Clean the shock absorber rod. Use a wire brush. Use WD-40 spray.

39



Install the spring on the shock absorber.

40



Compress the spring.

41



Install the upper strut mount and the strut mount bearing.

42



Tighten the shock strut piston rod nut. Use a drive socket #21. Use HEX No.H6. Use a torque wrench. Tighten it to 60 Nm torque.

Replacement: coil springs – VW Touran 1T3. Tip from AUTODOC experts:

- Check to make sure the spring is positioned correctly. Avoid its misalignment.

43



Decompress the spring.

44



Remove the assembled shock strut.

45



Install the shock strut into the wheel arch. Tighten the shock strut top mount. Use a drive socket #13. Use a ratchet wrench.

46



Fix the shock absorber strut on the steering knuckle. If necessary, use a rubber mallet.

47



Mount the drive shaft into the wheel hub.

48



Attach the ball joint to the control arm.

49



Screw in the fasteners of the ball joint lock plate (3 pieces). Use a drive socket #16. Use a torque wrench. Tighten it to 40 Nm torque.

50




Install and tighten a new bolt of the steering knuckle. Use a combination spanner #18. Use XZN #14. Use a drive socket #18. Use a torque wrench. Tighten it to 130 Nm torque.

Please note!

- The tightening torque is indicated for a steel steering knuckle.

51



Secure the stabilizer link on the suspension strut. Use a combination spanner #18. Use XZN #6. Use a torque wrench. Tighten it to 65 Nm torque.

52



Fasten the brake hose on the strut. Connect the fastener of the ABS sensor cable to the shock absorber strut.

53



Install and tighten the drive shaft bolt. Use 15/16" drive 12-point socket.

54



Clean the wheel rim mounting seat. Use a wire brush. Treat the contacting surface. Use copper grease.

55



Install the wheel.


AUTODOC recommends:

- Warning! To avoid injury, hold the wheel while screwing in the fastening bolts on the car. VW Touran 1T3

56



Screw in the wheel bolts. Use wheel impact socket #17.

57


Tighten the bolt connecting the drive shaft to the wheel hub. Use 15/16" drive 12-point socket. Use a torque wrench. Tighten it to 200 Nm torque.

58


Install the wheel rim cover.

59


Lower the car and working in a cross order, tighten the wheel bolts. Use wheel impact socket #17. Use a torque wrench. Tighten it to 120 Nm torque.

60


Tighten the shock strut top mount. Use a drive socket #13. Use a torque wrench. Tighten it to 15 Nm torque.

61


Clean the mounting seat of the cowl grille.

62



Install and secure the cowl grille.

63



Clean the pivots of the windscreen wiper arms. Use a wire brush. Treat the pivots of the windscreen wiper arms. Use copper grease.

64



Reinstall the wiper arms.

65



Tighten the fasteners of the wiper arms. Use a drive socket #14. Use a torque wrench. Tighten it to 10 Nm torque.

Replacement: coil springs – VW Touran 1T3. Professionals recommend:

- Make sure not to mix up the wiper arms on the driver's and passenger's sides.

66



Install the cowl grille seal.

67



Remove the jacks and chocks.

68



Close the hood.

**DID YOU FIND THESE INSTRUCTIONS
HELPFUL?**

YES

NO



BECOME A MEMBER OF AUTODOC CLUB!

AUTODOC — TOP QUALITY AND AFFORDABLE CAR PARTS ONLINE

AUTODOC MOBILE APP: GREAT DEALS AND CONVENIENT SHOPPING



AUTODOC
APP

Download

 Google play

 App Store

A GREAT SELECTION OF SPARE PARTS FOR YOUR CAR



BUY SPARE PARTS FOR VOLKSWAGEN



COIL SPRINGS: A WIDE SELECTION



CHOOSE CAR PARTS FOR VW TOURAN 1T3



COIL SPRINGS FOR VW: BUY NOW



COIL SPRINGS FOR VW TOURAN 1T3: THE BEST DEALS & OFFERS



Disclaimer:

The document contains only general recommendations that may be useful for you when you perform repair or replacement work. AutoDoc shall not be liable for any loss, injury, damage of property occurring in the repair or replacement process due to incorrect use or misinterpretation of the provided information.

AutoDoc shall not be liable for any possible mistakes and uncertainties in this guide. The information provided is for information purposes only and cannot replace advice from specialists.

AutoDoc shall not be liable for incorrect or hazardous usage of equipment, tools and car parts. AutoDoc strongly recommends to be careful and observe the safety rules when performing repair or replacement works. Remember: usage of low quality auto parts does not guarantee you the appropriate level of road safety.

© Copyright 2018 – All the contents of this website, in particular texts, photographs and graphics, are protected by copyright. All rights, including reproduction, publication, editing and translation rights, are reserved by Autodoc GmbH.